


QUICK GUIDE

WIPEBOT

Thank you for purchasing our window cleaning robot, this "Quick use guide" can help you quickly get familiar with and use this product. For more detailed product information, please read the product manual and warranty certificate.

PRODUCT OVERVIEW

1. Start / Pause button
2. ON / OFF power button
3. Air outlet
4. Signal receiver
5. Charging indicator
6. Error indicator
7. Power line
8. Safety rope mounting hole
9. Mop holder
10. Bottom signal receiver
11. Bottom error indicator (green)
12. Bottom error indicator (red)



PARTS LIST




Window cleaning robot



Remote control



Mop holder x2



Mops x12



100 ml sprayer



Safety rope




Charging plug



Power adapter



User manual



Quick start guide

REMOTE CONTROL



▶/⏸ 1. Pause / Continue

⏴ 2. Move down to the end of the glass

⏵ 3. Move up to the end of the glass

⏴ 4. Move left to the end of the glass

⏵ 5. Move right to the end of the glass

x1 6. Cleaning once

x2 7. Cleaning twice

⏴ 8. Continue to clean and move up from the current position

⏴ 9. Continue to clean and move left from the current position

⏴ 10. Continue to clean and move right from the current position

QUICK GUIDE

WIPEBOT

▶ INSTALLATION INSTRUCTIONS



1. Ensure the knob of the safety rope is fully tightened to the frame. We recommend to fasten the buckle side of the safety rope to an object which is strong enough and will not be dragged, and reserve a suitable length for the device to work.



2. Cover the holder with a mop.



3. Install the mop holders covered with a mop to the round cleaning roller. After installation, stand beside and observe the connection between the mop holder and the cleaning roller. Ensure they are tightly connected and flush with each other, and have no air leakage.



4. Insert the window cleaner power cord to the end of the adapter and tighten them.

▶ OPERATION INSTRUCTIONS AND ATTENTIONS

1

SAFETY ROPE.

Carefully inspect the safety rope, ensure there's no damage on it and that it is tightly buckled to an object.

2

INSPECTION OF THE WORKING ENVIRONMENT.

Guarantee the glass is dry. Don't use this device under the condition of rain, or when the glass is wet and has mist on it. Don't use this product on the surface of a damaged glass, or if the glass has cracks on it.

When the product is working high above the ground at outside, it's necessary to set ground safety warnings which can avoid personal injuries caused by accident.

3

CLEANING.

In case of sand and dust on the surface of the glass, please clean it with a dry cloth; otherwise, the wet cloth will mix with the sand and dust, and scrap the glass. When there is no sand and dust, lightly spray 2-3 times of the cleaning agent on the lower mop, don't make the lower mop all wet; don't spray on the upper mop, keep it dry. Fill water in the sprayer, then put a cleaning tablet in it. After the cleaning tablet is completely dissolved in water, the cleaning agent is prepared.

4

GETTING STARTED.

Ensure the power line and plug are completely connected.

Long press the power button (more than 3 seconds), the robot will get started. After the fan is running, attach the robot to the location far away from the window frame. Ensure the robot is stuck on the window, and then release it. Press the Start button and the product will start running.

5

TAKING DOWN THE ROBOT.

When the robot is running, hold the safety rope with one hand, and take down the robot with the other hand.

If your hand can't reach the robot, please use the remote control or safety rope and pull it back.

Pull the robot from one side which is as close to the glass as possible, prevent it from dropping out. After completely taking down the robot, long-press the power button (more than 3 seconds) to stop it.

6

POWER-OFF PROTECTION.

This robot is equipped with an internal battery, which can hold on the robot for twenty minutes in case the robot is accidentally removed from the power cord and it will raise an audible and visual alarm.

Please take down the robot as soon as possible.

When the electric quantity of the internal battery is too low to start the robot, please charge the built-in battery.

Turn off the robot and connect it to the power line. When the blue lamp is flashing, it means that the robot is under the condition of charging; when the blue lamp is fixed, it means that the robot is fully charged.